

Assembly Numbers

KINEDIZER® LE burners

To order a KINEDIZER® LE burner, enter configured item number: KINEDIZER LE

Segment name	Segment description	Segment choices (DEFAULT is shaded)	Segment choice description
BURNER SIZE	Select burner size, then segment choices below will be available at next level	015	(015) 1.5" size
		030	(030) 3" size
		040	(040) 4" size
		060	(060) 6" size
		080	(080) 8" size
		100	(100) 10" size
		120	(120) 12" size
		140	(140) 14" size
		160	(160) 16" size
MODEL NUMBER	Model number of burner	Calculated	Value will be calculated
FUEL	Type of fuel	N	(N) Natural gas
		P	(P) Propane
AIR INLET	Type of air inlet connection	F	(F) Flanged
		N	(N) No flange
BLOCK	Type of block	B	(B) Standard block
		S	(S) Block with sleeve
FIRING RATE MILLION BTU/HR	Specify firing rate	Enter value	---

Suggested spare parts									
Burner size	015	030	040	060	080	100	120	140	160
Spark ignitor	28548	28548	47789	47789	47789	47789	47789	47789	47789
Rubber cover	18722	18722	18722	18722	18722	18722	18722	18722	18722
Observation glass	19284	19284	37428	37428	37428	37428	37428	37428	37428
Block assembly	57453	1115392	57456	57457	57458	57459	1108253	59824	1106359
Block assembly with sleeve	48812	48814	48815	48816	48817	48818	1108254	59823	1106501
Block gasket	48414	48424	48448	48434	48440	48446	1108323	59822	1106470